

Primerdesign™ Ltd

**GMO event quantification**

# **Soya Round up Ready (RR)**

Detection and quantification of  
GMO integration events by real-time PCR

100 tests

**G E N E S I G**

Kits by Primerdesign

## Kit contents

- **Soya-WT DNA primer/probe mix (100 reactions BROWN)**
- **RR (GMO) DNA primer/probe mix (100 reactions BROWN)**
- **Positive control template (RED)**
- **GMO reference control sample (BLUE)**
- **RNase/DNase free water (WHITE)**  
for resuspension of primer/probe mixes
- **Template preparation buffer (YELLOW)**  
for resuspension of positive control template

## Reagents and equipment to be supplied by user

- **Real-time PCR Instrument**
- **oasig™ Lyophilised or Precision®PLUS 2X qPCR Master Mix**  
This kit is intended for use with oasig or PrecisionPLUS 2X qPCR Master Mix.
- **Pipettes and Tips**
- **Vortex and centrifuge**
- **Thin walled 0.2 ml PCR reaction tubes**

## Kit storage and stability

This kit is stable at room temperature but should be stored at -20°C on arrival. Once the lyophilised components have been resuspended they should not be exposed to temperatures above -20°C for longer than 30 minutes at a time and unnecessary repeated freeze/thawing should be avoided. The kit is stable for six months from date of resuspension under these circumstances.

## Suitable sample material

All kinds of sample material suited for PCR amplification can be used. Please ensure the samples are suitable in terms of purity, concentration and DNA integrity. Always run at least one negative control with the samples. To prepare a negative control, replace the test sample DNA with RNase/DNase free water.

## Notices and disclaimers

This product is developed, designed and sold for research purposes only. It is not intended for human diagnostic or drug purposes or to be administered to humans unless clearly expressed for that purpose by the Food and Drug Administration in the USA or the appropriate regulatory authorities in the country of use. During the warranty period Primerdesign genesig detection kits allow precise and reproducible data recovery combined with excellent sensitivity. For data obtained by violation to the general GLP guidelines and the manufacturer's recommendations the right to claim under guarantee is expired. PCR is a proprietary technology covered by several US and foreign patents. These patents are owned by Roche Molecular Systems Inc. and have been sub-licensed by PE Corporation in certain fields. Depending on your specific application you may need a license from Roche or PE to practice PCR. Additional information on purchasing licenses to practice the PCR process may be obtained by contacting the Director of Licensing at Roche Molecular Systems, 1145 Atlantic Avenue, Alameda, CA 94501 or Applied Biosystems business group of the Applied Biosystems Corporation, 850 Lincoln Centre Drive, Foster City, CA 94404. In addition, the 5' nuclease assay and other homogeneous amplification methods used in connection with the PCR process may be covered by U.S. Patents 5,210,015 and 5,487,972, owned by Roche Molecular Systems, Inc, and by U.S. Patent 5,538,848, owned by The Perkin-Elmer Corporation.

## Trademarks

Primerdesign™ is a trademark of Primerdesign Ltd.

genesig® is a registered trademark of Primerdesign Ltd.

The PCR process is covered by US Patents 4,683,195, and 4,683,202 and foreign equivalents owned by Hoffmann-La Roche AG. BI, ABI PRISM®, GeneAmp® and MicroAmp® are registered trademarks of the Applied Biosystems (Applied Biosystems Corporation). BIOMEK® is a registered trademark of Beckman Instruments, Inc.; iCycler™ is a registered trademark of Bio-Rad Laboratories, Rotor-Gene is a trademark of Corbett Research. LightCycler™ is a registered trademark of the Idaho Technology Inc. GeneAmp®, TaqMan® and AmpliTaqGold® are registered trademarks of Roche Molecular Systems, Inc., The purchase of the Primerdesign™ reagents cannot be construed as an authorization or implicit license to practice PCR under any patents held by Hoffmann-LaRoche Inc.

# Introduction

The soybean line GTS 40-3-2 was developed to allow for the use of glyphosate, the active ingredient in the herbicide Roundup®, as a weed control option for soybean. This genetically engineered soybean variety contains a glyphosate tolerant form of the plant enzyme 5-enolpyruvylshikimate-3-phosphate synthase (EPSPS) isolated from the common soil bacterium, *Agrobacterium tumefaciens* strain CP4 (CP4 EPSPS).

# Principles of the test

This kit provides a method for detecting gene insertion events by real-time PCR. The kit is based on the PCR amplification and detection across the integration site of the inserted genetic marker. This DNA sequence is artificial and therefore only detectable in a genetically modified organism (GMO) containing that specific modification.

## Real-time PCR

The primer and probe mixes provided exploit the so-called TaqMan® principle. During PCR amplification, forward and reverse primers hybridize to the sample DNA. Fluorogenic probes are included in the reaction mixtures which consists of a DNA probe labeled with a 5`-dye and a 3`-quencher. During PCR amplification, the probe is cleaved and the reporter dye and quencher are separated. The resulting increase in fluorescence can be used to detect genetically modified DNA present in the sample.

As well as primers and probe that detect the insertion event, the kit also contains primers and probe to detect the wild-type sequence. Also included is a control DNA containing GM DNA at a ratio of 1 part in 100 (1% GMO). This enables the proportion of GM DNA present in any given sample to be calculated.

## GMO Event specific primer and probes

The kit provides “event specific” primers and probe that detect a GM insertion event. The primers and probe are read through the FAM channel and detect the presence of the precise DNA modification event under test and no others.

## Wild-type control primers and probe

The kit also provides primers and probe to detect the endogenous wild-type DNA of the host plant. These primers and probe are also detected through the FAM channel and are tested in a separate well. Detection of the wild-type DNA indicates that the extraction process has been successful. With detection levels of the wild-type sequence enabling calculation of the proportion of modified DNA included in the sample. This is critical for determining the % of GM DNA in mixed populations of plants.

## Positive control for RR and Soya sequences

The kit provides a positive control template for both primer and probes sets. The positive control enables the user to obtain positive traces thereby proving that the PCR reactions have been set up and run correctly. A positive control for each primer set should be included each time a run is performed. The PCR amplicons for the two primer sets have been cloned into the same vector so that the same positive control template can be used for both primer sets.

### **GMO reference control sample (crushed seeds)**

The kit contains crushed wild-type seeds which have been spiked with GMO seeds at a level of 1%. The DNA extracted from this sample is a control for the extraction process to show that DNA can be successfully extracted using your extraction protocol. Data from this control sample for the wild-type primer set and event specific primer set can be used to calculate the percentage of GM DNA present in test samples.

# Resuspension protocol

To minimise the risk of contamination with foreign DNA, we recommend that all pipetting be performed in a PCR clean environment. Ideally this would be a designated PCR lab or PCR cabinet. Filter tips are recommended for all pipetting steps.

## 1. Pulse-spin each tube in a centrifuge before opening

This will ensure the lyophilised primer/probe mix is in the base of the tube and is not spilt upon opening the tube.

## 2. Resuspend the primer/probe mixes in the RNase/DNase free water supplied, according to the table below:

To ensure complete resuspension, vortex each tube thoroughly.

Component – Resuspend in water	Volume
<b>Pre-PCR pack</b>	
Soya primer/probe mix ( <b>BROWN</b> )	110 µl
RR primer/probe mix ( <b>BROWN</b> )	110 µl

## 3. Resuspend the positive control template in the template preparation buffer supplied, according to the table below:

To ensure complete resuspension, vortex the tube thoroughly.

Component – Resuspend in template preparation buffer	Volume
<b>Post-PCR heat-sealed foil</b>	
Positive control template ( <b>RED</b> ) *	500 µl

\* This component contains high copy number template DNA and is a significant contamination risk. It must be opened and handled in a separate laboratory environment, away from the other components.

# DNA extraction

## Perform DNA extraction on test samples and crushed seeds according to the DNA extraction kit protocol.

The crushed seeds should be extracted in parallel and using the same protocol as for all of the samples under test.

N.B. the kit contains the correct amount of seeds required for 1 extraction only.

## qPCR detection protocol

**1. Prepare complete reaction mixes for each target primer/probe mix according to the table below:**

Include sufficient reactions for positive and negative controls as well as each sample and extracted crushed seeds.

Component	1 reaction
oasig or PrecisionPLUS 2X qPCR Master Mix	10 $\mu$ l
<b>Soya or RR primer/probe mix (BROWN)</b>	1 $\mu$ l
RNase/DNase free water (WHITE)	4 $\mu$ l
<b>Final volume</b>	<b>15 <math>\mu</math>l</b>

**2. Pipette 15 $\mu$ l of each mix into individual wells according to your qPCR experimental plate set up.**

**3. Prepare sample DNA templates for each of your samples.**

**4. Pipette 5 $\mu$ l of DNA template into each well, according to your experimental plate set up.**

For negative control wells use 5 $\mu$ l of RNase/DNase free water. The final volume in each well is 20 $\mu$ l.

**5. Pipette 5 $\mu$ l of positive control template into the positive control wells.**

The final volume in each well is 20 $\mu$ l

## qPCR amplification protocol

Amplification conditions using oasig or PrecisionPLUS 2X qPCR Master Mix

	Step	Time	Temp
Cycling x50	Enzyme activation	2 min	95°C
	Denaturation	10 s	95°C
	<b>DATA COLLECTION*</b>	60 s	60°C

\*Fluorogenic data should be collected during this step through the FAM channel.

# Interpretation of results


Results from both the test sample and the reference control can be analysed using the table below to determine whether a result can be called as positive or negative.

GMO Target (FAM)	WT Soya (FAM)	Positive control	Negative control	Interpretation
+	+	+	-	<b>POSITIVE QUANTITATIVE RESULT</b> Calculate GMO %
+	-	+	-	<b>POSITIVE QUALITATIVE RESULT</b> Do not attempt to calculate GMO %
-	+	+	-	<b>NEGATIVE RESULT</b>


+ / -	+ / -	+	$\leq 35$	<b>EXPERIMENT FAILED</b> Due to test contamination
+ / -	+ / -	+	$> 35$	*
-	-	+	-	<b>INAPPROPRIATE SAMPLE TYPE / PREPARATION FAILURE</b>
+ / -	+ / -	-	+ / -	<b>EXPERIMENT FAILED</b>

Positive control template (**RED**) is expected to amplify between Cq 16 and 23. Failure to satisfy this quality control criterion is a strong indication that the experiment has been compromised.

\*Where the test sample is positive and the negative control is positive with a Cq  $> 35$ , the sample must be reinterpreted based on the relative signal strength of the two results:



If the sample amplifies  $> 3$  Cq earlier than the negative control then the sample should be reinterpreted (via the table above) with the negative control verified as negative.



If the sample amplifies  $< 3$  Cq earlier than the negative control then the positive sample result is invalidated and a negative call is the correct result.

## Calculating GMO %

If both the test sample and reference control produce positive quantitative results, the presence of the GMO sequence within a sample can be calculated in percentage terms using the formulae below:

**Step 1:** Calculate the relative WT Soya amounts

$$\text{WT Soya Relative Amount} = 2^{-(\text{WT Soya Sample Cq} - \text{WT Soya Reference Control Cq})} \times 99$$

**Step 2:** Calculate the relative GM RR amounts

$$\text{GM Relative Amount} = 2^{-(\text{GM RR Sample Cq} - \text{GM RR Reference Control Cq})}$$

**Step 3:** Calculate GM percentage

$$\text{GM Percentage} = \frac{\text{GM RR Relative Amount}}{\text{WT Soya Relative Amount} + \text{GM RR Relative Amount}} \times 100$$

Worked example

Test sample

WT event target Cq = 25

GMO event target Cq = 29

1% GMO Reference control (supplied)

WT event target Cq = 26.5

GMO event target Cq = 32

$$\text{Step 1: } 2^{-(25-26.5)} \times 99 = 280.01$$

$$\text{Step 2: } 2^{-(29-32)} = 8$$

$$\text{Step 3: } [8 \div (280.01 + 8)] \times 100 = 2.77\%$$

The test sample percentage = 2.77%